

MORE TOOLS

Leak Alert™



Electronic Water Detector

Protect your home from water damage with Leak Alert™

Place Leak Alert anywhere there is a danger of flood or leaks, near water heaters, sinks, dishwashers, or sump pumps.

Leak Alert sounds a very loud alarm when it gets wet for up to 72 hours.

Place anywhere the potential for flooding or leaking exists:

- Under sinks
- Near water heater
- In basements
- Near dishwashers and refrigerators
- Under fish tanks
- Near plumbing and toilets



SPECIFICATIONS

Dimensions:	1.4 in. H x 2.4 in. W x 4.3 in. L (35 mm x 60 mm x 108 mm)
Weight:	2.3 oz. (66 g) without battery
Battery Type	9-V alkaline (not included)
Low Battery Indicator	Unit will beep to indicate low battery
Battery Life	72 hours of continuous use (up to two years depending on use)
Sound Intensity	95dB at 10 feet (3 m)
Operating Temperature:	32°F to 120° (0°C to 49°C)
Storage Temperature:	-20°F to 150° (-29°C to 66°C)
Humidity:	80% (non-condensing)
Shock Resistance	Shock resistant from a 6-foot (1.8 m) drop onto concrete
Water Resistance	Splash and water resistant, not waterproof (floats on surface)

- Loud alarm (95 dB) sounds with direct water contact
- Floats and signals for up to 72 hours
- Fully automatic operation—no wiring required
- Low battery indicator for optimum safety and performance